## **Revision and Errata List AISC Steel Construction Manual, 16th Edition (1st Printing)**

## Date: March 27, 2024

The following list represents corrections to the First Printing of the AISC *Steel Construction Manual*, 16th Edition. The Specifications found in Part 16 of the *Manual* have their own revisions and errata lists.

Page(s)	Item
1-40, 1-42	Revise "Area" units to in. <sup>2</sup> from in. <sup>4</sup>
2-8	Under Safety Cables, item 2, change "walking surface" to "finished floor."
3-78	In the S-shape figure on the left-hand side of the top of the page, change W10-S6 to S10-S6
6-106	Under Point "D" defining equations:
	1) Revise " $M_D$ " equation as follows (change " $Z_{cn}$ " to " $Z_c$ "):
	$M_{D} = F_{y}Z_{s} + F_{yr}Z_{r} + 0.85f_{c}'\left(\frac{Z_{c}}{2}\right)$
	2) Replace the " $Z_{cn}$ " equation with the following:
	$\mathbf{Z}_{c} = \frac{h_{t}h_{2}^{2}}{4} - \mathbf{Z}_{s} - \mathbf{Z}_{r}$
6-108	In the lower right box on the page, the moment equation for point B should show " $M_B$ " (not " $M_D$ ").
8-15	The figure reference in the first sentence of "Elastic Method" should read "Figure 8-5(a)" instead of "Figure 8-6(a)."
8-66	The title of the table on page 8-66 is changed to: "Prequalified Welded Joints Flare Bevel Flare-V Groove Welds"
9-42	Add the following limit to Equation 9-42:
	$\alpha_r = \frac{1}{\delta} \left[ \frac{T_r}{T_c} \left( \frac{t_c}{t} \right)^2 - 1 \right] \underline{\text{with } 0 \le \alpha_r \le 1.0}$
9-50 to 9-51	In Table 9-3c, the heading of the first column should be " $l_{ev}$ " (not " $l_{eh}$ ").
10-13	The second full sentence on the page to be corrected as follows: "Values above the heavy line are governed by the limit state of block shear rupture."
10-36	In the bottom portion of the second page of Table 10-5, under "Connection Type", it should read: "D (3 bolts)", "E (6 bolts)", and "F (9 bolts)" [instead of "A (2 bolts)", "B (4 bolts)", and "C (6 bolts)"].
10-49	In the <i>Dimensional Limitations</i> Section, limitation 4 should reference AISC <i>Specification</i> Table J3.4 (not Table J3.5).

Page(s)	Item
10-105	In the lower right-hand case, the groove weld symbol "S" is changed to "D" and "E" is changed to "S".